



G63 SHADOWSTRIKE


SOMIC | Tournament-Grade Wireless Gaming Headset

Bluetooth Version: V5.4
Bluetooth Device Name: SOMIC G63
2.4G Mode Device Name: SOMIC G63 Dongle
USB Wired Mode Device Name: SOMIC G63 Headset
Transmit Power: CLASS 2
Wireless Range: Approx. 10 meters
Operating Frequency Range: 2402MHz-2480MHz
Built-in Battery Capacity: 2000mAh
Adapter Rating: DC 5.0V/2A

Note: All images in this manual are for illustrative purposes only. Actual product may vary.


PRODUCT OVERVIEW

PART 1




PRODUCT OVERVIEW

PART 2



2.4G MODE CONNECTION

PART 3



* Dongle Pairing (Factory Default: Paired): Insert the USB dongle into the host device. With the headset powered on and switched to 2.4G mode, press and hold the Multi-Function Button and the Power Button for 5 seconds. The device will power on and reset successfully, allowing you to re-pair with the 2.4G dongle.

* When manually pairing, keep the headset as close to the dongle as possible.

DRIVER INTRODUCTION

PART 4


SOMIC Client Driver: <https://www.somic.cn>

Open the website in your browser, click [After-Sales Service]→[Driver Download]→[Search G63], and you can download the "G63 Headset" client driver.

* Currently supports Windows 10 and above only. Windows 7 and macOS are not supported at this time.

BLUETOOTH MODE CONNECTION

PART 5




* If the headset disconnects due to exceeding the range, it will automatically reconnect to the device when it returns within range. If no device is reconnected within 5 minutes, the headset will automatically power off.

* Bluetooth Factory Reset: Press and hold the Multi-Function Button and the Power Button for 5 seconds. Once reset is successful, you can re-pair via Bluetooth.


(If the original device has a saved connection record, please delete it manually.)

SOUND CARD MODE CONNECTION



* With the headset powered on, connect the Type-C data cable to the headset and plug it into the host device, then double-press the Power Button to enter Sound Card mode. (Play while charging)

CHARGING STATUS



* To prevent battery damage and extend the lifespan of the headset, please use the included cable and a standard power charger. Do not use high-power fast chargers.

TIPS

PART 7

- Driver Acquisition:** For products requiring drivers, please visit the SOMIC official website's Download Center to obtain the corresponding driver and user documentation for your model. Some products support driver-free, plug-and-play functionality.
- System Compatibility:** Currently compatible with Windows 10, Windows 11 (32-bit / 64-bit), and Apple iMac systems. For compatibility with other operating systems or devices, please consult after-sales support.
- Environmental Requirements:** Recommended for indoor use with an ambient temperature range of -10°C to 40°C. Avoid direct sunlight, moisture, and strong magnetic fields to prevent water ingress or equipment damage.
- Safety and Maintenance:**
 - If any component is damaged (such as frayed cables or worn ear cushions), discontinue use and contact after-sales service for repair or replacement.
 - Do not wear the headset for extended periods. It is recommended to limit continuous wearing to no more than 3 hours per session. To avoid potential safety hazards, do not wear the headset while sleeping, walking, driving, or in similar scenarios.
 - The product may experience software incompatibility with sound cards of certain brands. It is recommended to use this product independently.
 - Do not use non-original charging accessories to prevent equipment damage or short circuits.
- Driver Support:** The official website will periodically update driver versions; please check for downloads regularly. If you encounter driver compatibility issues or other usage problems, please contact after-sales technical support promptly.